

SRV: PLASTIC VALVE

ITEM	DESCRIPTION		CATALOG NO.
1	Solenoid Assembly (Includes 2 & 3)	AC Solenoid	606800
		DC Solenoid	458200
2	O-Ring		262600
3	Solenoid Seal		364400
4	Bonnet Screw		427300
5	Bonnet without Flow Control		556100
6	Bonnet with Flow Control		556000
7	Diaphragm Spring		266000SP
8	Diaphragm Assembly		332100SP
9	Diaphragm Support Ring		331300SP
10	Flow Control Handle Black		269200

